


Datamate Tooling

❖ Instruction sheets (where available) can be accessed at www.harwin.com/downloads/instructions

SEPARATOR TOOL

- ❖ Recommended for unplugging L-Tek latched connectors (tool releases the latches prior to disengagement).
- ❖ Can also be used with unlatched and friction lock connectors.
- ❖ Suitable for all sizes.



ORDER CODE

L-Tek	T5746
-------	--------------

INSERTION/REMOVAL TOOL

- ❖ For inserting crimped contacts into the rear of mouldings.
- ❖ Instruction sheet available.
- ❖ Suitable for all Datamate signal contacts.



ORDER CODE

Signal crimps for L-Tek, J-Tek & Mix-Tek	Z80-280
--	----------------

HAND CRIMP TOOL

- ❖ Standard coax crimp tool for crimping the outer sleeve of Mix-Tek coax contacts.
- ❖ Instruction sheet available.



ORDER CODE

Outer sleeve of Mix-Tek coax contacts	Z80-293
---------------------------------------	----------------

REMOVAL TOOL

- ❖ To aid removal of special cable contacts from Mix-Tek connectors.



ORDER CODE

Mix-Tek special cable connectors	Z80-290
----------------------------------	----------------

www.harwin.com

